



Installation instructions for the DOLBY®-decoder

- Disconnect receiver from power outlet.
- Remove two Phillips screws and remove left hand side panel.
- Reach into the finger-holes of the cover plate, remove Phillips screw and take out cover plate.
- Remove dummy insert with the aid of a wire hook (or long-nose pliers).
- Insert Dolby decoder (shield facing down) and push it fully home.
- Re-install cover plate and side panel.

Instruction de montage du décodeur DOLBY®

- Déconnectez le receiver du secteur.
- Démontez la paroi gauche en dévissant 2 vis.
- Enlevez la tôle de protection en la maintenant par les trous et en dévissant la vis.
- Retirez le circuit fictif à l'aide du crochet ou d'une pince pointue.
- Enfichez le décodeur Dolby (blindage en bas).
- Remontez la tôle de protection et la paroi de gauche.

Anleitung zum Einbau des DOLBY®-Decoders

- Receiver vom Netz trennen.
- 2 Kreuzschlitzschrauben lösen, linke Seitenwand abnehmen.
- Deckblech in den Löchern halten, Kreuzschlitzschraube lösen und Deckblech abnehmen.
- Blindeinsatz mit Draht-haken (oder Spitzzange) herausziehen.
- Dolby-Decoder einsetzen (Abschirmung unten); ganz einstecken.
- Deckblech und Seitenwand wieder montieren.

